




SKU: F1
INSTALLATION INSTRUCTIONS:
Aluminum frame, with drywall inlay, for drywall walls and ceilings - System F1 - screwed panel.
TOOLS REQUIRED:

Screwdriver

Set square

Tape measure



Level

Drywall saw/Utility knife
MEASURING AND CUTTING THE ROUGH OPENING


01. Determine the location for the Access Panel and note the position of studs or joists.
02. Measure the inside dimensions of the frame (not the door). Add $\frac{3}{4}$ " (9 mm) to each dimension.
03. Mark a pair of base lines 90° to each other on the ceiling or wall where the hole will be. These must be a minimum of $1\frac{1}{4}$ " (32 mm) and a maximum of 4" (102 mm) away from a stud or joist. Mark the opposite sides using the dimensions in Step 2. Accurate marking is very important and make sure that the lines are square.
04. Cut the opening with a knife, saw or drywall cutter. Make sure the edges are clean.

FRAME (SHOWN WITH HATCH OPEN)

A and B are the dimension of opening in the frame



OPENING IN GYPSUM WALL BOARD

STANDARD CEILING AND WALLS STUD OR JOISTS AT 16" (406 MM) CENTER

The illustration below shows the maximum size of the frame that fits between joists or studs on standard center.




SKU: F1
INSTALLATION INSTRUCTIONS:

Aluminum frame, with drywall inlay, for drywall walls and ceilings - System F1 - screwed panel.


■ MAXIMUM & MINIMUM CLEARANCE TO STUDS FROM CUT OPENING


Please Note: Check to make sure frame is square before installing all the screws to insure proper operation of the door.


Important: This panel can be installed in the wall right or left handed or so the panel tips out to open. If the panel is going into the ceiling, Please install the latches away from the wall for easier operation.

Drywall insert with screws on sizes larger than 24" x 24" (610 mm x 610 mm).


1 Pass the Access Panel through the opening and pull firmly back after opening hatch.



2 Screw through the drywall into the frame of the Access Panel. The maximum distance between screws is 4" (102mm)



Minimum
one screw
per 4"




Recommended screw




Safety cap



3 Test the door opens correctly. Apply drywall compound.



4 Clean the frame and the door with a damp cloth.



5 Install safety cable.

